



Blacklight Tours Ltd

373 Station Road

Forest Gate

London

E7 0AB

Tel: **0207 993 6665**

Stanford Coachworks

Mobility House

Stanhope Industrial Estate

Wharf Road

Stanford le Hope

Essex

SS17 0EH

Tel: **01375 676088**



USER GUIDE **J4260**



BLACKLIGHT TOURS: PEUGEOT BOXER USER GUIDE

MINIBUS CONVERSIONS | LUXURY COACHES | WHEELCHAIR ACCESSIBLE VEHICLES | AMBULANCE CONVERSIONS

HOW TO WORK THE TV & SOUND



STEP 1

Ensure that the ignition is turned on and press the 'Power on' and 'Media on' buttons. These are located to the right of the steering wheel. Press the 'Override' button if you wish to override the 15 minute timer to continue powering the vehicle.



STEP 2

The Apple TV will then display on the screen. This can be controlled by the remote which is circled in the photo to the left.



STEP 3

The soundbar can be found above the door that leads into the production area. To turn this on press the small power button shown in the photo to the left. The yellow arrow points directly towards the button.



LIGHTS AND HDMI SOCKET

A HDMI socket can be found on the right window sill. The buttons to the outer control the lights. The left button turns on the white LED lights and the right button turns on the blue LED lights.



RUNLOCK & REVERSE BUZZER

Located to the right of the steering wheel are the 'reverse buzzer' and 'runlock' buttons. The reverse buzzer can be turned on to sound when reversing to alert pedestrians. Press the runlock button if you want the vehicle to continue running without having a key in the ignition.



FUSE BOX

The fuse box is situated underneath the double cab passenger seats. A map for the fuse box can be found in the vehicle's book pack.



SAFE

The safe is situated behind the single passenger seat.

The code for the safe is **489**. It can also be opened using the safe key.



HEATER


The rear saloon heater is located to the right of the drivers steering wheel. Please refer to the Eberspacher guide which can be found in your vehicle folder for instructions on how to use.



CODED DOOR

The coded door allows access into the production area. The code for this door is **C489**.

EXTERNAL HOOK UP



The external hook up can be found on the drivers side of the vehicle. This can be used to power the equipment on board instead of running on the vehicles battery.

PRODUCTION AREA



MIRROR AND LIGHTS

The switches next to the dressing table control the lights. The switch on the left controls the lights around the mirror. The switch on the right controls the ceiling lights.



PLUG SOCKETS

There are 2 plug sockets located in the production area. Please ONLY use the kettle and hairdryer which are provided for these sockets.



KETTLE & HAIRDRYER

A kettle and hairdryer is provided with the vehicle. Please use this equipment only.

INVERTER



The inverter is located behind the front cab passenger seats in the rear saloon. Make sure that the black switch is set to 'ON' and the green light is showing. If the red light begins to flash it means that the battery is running low therefore the ignition will need to be turned on in order to recharge the battery.